





- A function/piece of code is:
 - *Compute bound* if it has high operational intensity
 - Memory bound if it has low operational intensity
- The roofline model makes this more precise
- Blackboard

Roofline Measurements

- Tool developed in our group (G. Ofenbeck, R. Steinmann, V. Caparros-Cabezas, D. Spampinato) <u>http://www.spiral.net/software/roofline.html</u>
- You can use it in your project
- Example plots follow
- Get (non-asymptotic) bounds on I:
 - daxpy: y = αx+y
 - dgemv: y = Ax + y
 - dgemm: C = AB + C
 - FFT

3

4









Summary

- Roofline plots distinguish between memory and compute bound
- Can be used on paper
- Measurements difficult (performance counters) but doable
- Interesting insights: use in your project!

9